



Covid19 Facial Detection Tools



Team

- Jeremy Fraenkel (jeremyfraenkel@gmail.com)
- Sang Lee (drminix@gmail.com)
- Chris Weyandt (cweyandt@berkeley.edu)
- Ian Anderson (imander@berkeley.edu)

Goal

Detect people who are not obeying by covid guidelines (i.e. mask on or off) as well as measure their temperature.

Interactive UI Mode with Qt






Image browser website



Face/Mask detection models

Face/mask detection inference pipeline




Models

- 1) Haar Cascades
- 2) Res10_SSD
- 3) YoloFace


MobileNetV2

Mask detection models

- Deep Learning Framework:
 - Tensorflow/Keras
- Data source:
 - 600k face/masked face images (5GB)
- Model architecture:
 - MobileNet v2 -based
- Transfer learning
- Data augmentation
 - Crop, zoop, rotate, and etc..



Training and deploying models






IoT System Architecture and Deployment



Architecture



Infrastructure Deployment

- **.env:** stores user-defined environment variables for device and server configurations.
- **Makefile:** defines scripted targets for common actions such as docker builds, AWS deployment, edge device deployment
- **Terraform:** create, configure and destroy AWS services such as vpc, security roles, s3 buckets.
- **Ansible:** scripting of service deployment on target machines. Transfer docker-compose.yml; pull, run, stop container services at cloud and edge.

Ansible playbook for targeted deployment

```
TASK [s3 : remove temp file] *****
Tuesday 08 December 2020  09:07:11 -0600 (0:00:01.607)          0:00:07.297 *****
changed: [localhost]

PLAY [all] *****
skipping: no hosts matched

PLAY RECAP *****
localhost                : ok=7    changed=6    unreachable=0    failed=0    skipped=0    rescued=0

Tuesday 08 December 2020  09:07:12 -0600 (0:00:00.555)          0:00:07.852 *****
=====
s3 : Upload website index.html ----- 2.48s
s3 : Upload website javascript ----- 1.61s
s3 : Upload error.html ----- 1.52s
s3 : Write javascript template to file ----- 1.05s
s3 : remove temp file ----- 0.56s
s3 : create temporary file ----- 0.54s
include_vars ----- 0.05s
Playbook run took 0 days, 0 hours, 0 minutes, 7 seconds

Captured images can be viewed at the following URL:
http://w251-covid-maskdetector.s3-website-us-west-2.amazonaws.com

Mask detection stats can be viewed at the following URL:
http://34.210.77.165:8080
```




User Interface and Imaging




Thermal Imaging


- FLIR Lepton 3.5 LW Infrared Camera
 - <https://www.flir.com/products/lepton/>
 - \$199 - requires IO board
- GroupGets PureThermal2 USB Interface board
 - <https://groupgets.com/manufacturers/getlab>
 - \$119 with case
- GroupGets PureThermal UVC Capture Library
 - <https://github.com/groupgets/purethermal1-uv-capture>
- GroupGets fork of lib-uvc
 - <https://github.com/groupgets/libuvc>



Stereo camera alignment / Image Registration



Stereo camera alignment / Image Registration



Github Repository

<https://github.com/cweyandt/mask-and-fever-detector>

Questions?